

Denotes connector No.
 The same connector No. is used throughout the circuit diagrams to facilitate connector location search.
 The first alphabetical symbol indicates the location site of the connector and a number that follows is the unique number.
 Numbers are usually assigned to part in clockwise order on the diagram.

Example: A-19

- Number specific to connector (serial number)
- Connector location site symbol
- A: Engine compartment
- B: Engine
- C: Transmission
- D: Dash panel
- E: Floor and roof
- F: Door
- G: Back door

Denotes earth point.
 Same earth number is used throughout circuit diagrams to facilitate search of earth point.
 Refer to GROUP 70 COMPONENT LOCATIONS - EARTH MOUNTING LOCATIONS for details of earth points.

Denotes harness name.

Denotes a section covered by a corrugated tube.

The mark ★ shows the standard mounting position of wiring harness.

Denotes the colour of the tube
 (If not specified, it is black).
 R: Red
 Y: Yellow

The number of connector pins and the connector colour (except milk white)* are shown for ease of retrieval.

Example: (2-B)

- Connector colour (milk white if no colour is indicated)
- Number of connector pins

*: Typical connector colours

- B: Black
- Y: Yellow
- L: Blue
- G: Green
- R: Red
- BR: Brown
- V: Violet
- O: Orange
- GR: Grey
- None: Milk white

A-19

1

Front wiring harness (RH)

A-18

A-17

A-16

A-15

- A-15 (2)
- A-16 (2-GR)
- A-17 (2-B)
- A-18 (2-B)
- A-19 (2-GR)

- Fog lamp (RH)
- Horn (LO)
- Headlamp (RH)
- Windshield washer motor
- Dual pressure switch

Indicates the device to which the connector is connected.